

RV760 with Wireless Backup Camera “Pairing”

Pair button – The pair button is a small bottom (see image) that comes on all OEM kits. This button is on the PND a small module that snaps into the rear of the RV760 monitor. All BC 20 accessories should already be paired from our factory and set-to go from the OEM production line on onto the dealer----- a pairing process should **not** be needed. If there occurs an instance where the OEM QC detects before shipping or the unit is at a dealership and pairing is not in place please do the following:

- ❶ **Hold the pair button down for 3 seconds ---- this will initiate the pair process.**
A black screen with “Start Pairing” text should appear.
- ❷ **Make sure all power to camera is off. This must happen in order to “pair”. Turn on the power or awake the camera to signal to the antenna in the power cord of the 12V --- powering the RV760 monitor.**
- ❸ **“Pairing Done” --- will appear on the monitor screen and this will signal that the monitor and camera have now recognized each other and one final step is needed.**
- ❹ **SHUT OFF power to all ! Both the camera and monitor at this point need to be turned off for about 6 seconds. When flipped back on all should be in sync.**
- ❺ **An image of the rear camera’s view is now on the screen with an ICON of the camera in the upper right hand corner of the monitor. This will now always remain paired. There should not be a need for this process again.**

