



PLACE 1/3 AND GROUND INSERT AT 1/3 VOLUME.

PLACE GROUND INSERT NO LESS THAN 10 in. FROM OTHER INSERTS IN HOLDING AND GREY TANKS. USE ALL AVAILABLE SPACE.

ALL HOLDING & LPG TANK GROUNDS MUST BE ATTACHED TO MONITOR GROUND.

MP5 PROBE INSTALLATION

MARK TANK PER PLACEMENT GUIDE.
DRILL HOLES USING 3/8 in. BIT. DRILL AT LOW SPEED.
INSERT MP1 INTO HOLE
REMOVE TOP 3/8 in NUT
TIGHTEN BOTTOM NUT UNTIL SNUG, DO NOT OVER TIGHTEN
* USE NUT DRIVER, DO NOT USE SCREW GUN
ATTACH WIRE WITH NUT REMOVED EARLIER
SEAL EXPOSED CONNECTIONS WITH RED BATTERY SPRAY OR
SILICON SEALER