Winterization Procedures for B&B Products

Water Fill Products & Exterior Showers

- 1) Disconnect city water supply
- 2) Open all hot/cold faucets including outside shower or exterior quick connect faucet (Docking Station Products)
- 3) Open low point drain until water stops draining, then close drain
- 4) Actuate hot water heater bypass valves per supplier instructions
- 5) Siphon winterizing solution through fresh water pump (see manufacturer's instructions)
- 6) Inspect all hot/cold faucets to verify solution discharge through both hot & cold lines, then close faucets and turn off fresh water pump (including exterior shower)
- 7) Open low point drain, turn on pump until solution discharges
- 8) Close low point drain then turn off water pump
- 9) Remove exterior shower head & hose and place in unit

Quick Connect Faucet (Docking Station Products ONLY)

After entire plumbing system has been winterized, removed sprayer nozzle from the coil hose and insert hose into metal quick connect releasing quick connect valve stopper. Make sure hot/cold valves are in an open position. Hold the open end of the hose near the ground and drain the system. Disconnect hose & place in storage

Plastic Water Fill <u>Diverter Valve</u> in B&B "Docking Station" ONLY

When flushing system with winterizing solution, turn valve several times to make sure solution has adequately filled the lines in both directions. With low point drain open position and valve switched to tank fill (gravity) position, remove screen washer from inlet, and depress valve to allow any remaining water to drain. Then place screen washer and position handle in tank fill position. <u>CAUTION!!! DO NOT DEPRESS VALVE</u> WITH PRESSURE IN LINES!!!