WINEGARD

Sensar® RV Replacement Parts

Winegard repair parts are available at many RV dealers and/or service centers nationwide. For the dealer nearest you, call 1-800-288-8094, extension 1, or visit our website at www.winegard.com.

RV-2005 Amplified antenna head (replaces RV-2001 and RV2001A)

2120566 Non-amplified antenna head

RP-2900 2 Elevator tubes with 2 grommets / 4 pins / 4 retaining rings / adhesive rubber bumper

RP-2000 Leveling mount / 4 spacers / 2 pins / 2 rings (for models purchased before 1990)

RP-3000 Elevating gear

FC-5932 RG-59 Weatherproof connector (12 pack) RV-2005/2120566 RP-2900 **RP-2000 RP-3000 HIND**

SA-1001 Ivory preassembled elevating shaft / gear housing / base plate

RP-4000 Worm gear and 12.25" hex elevating shaft

(complete assembly including: wave washer / flat washer / o-ring / worm gear nut)

RP-4014 Worm gear and 14" hex elevating shaft

(complete assembly including: wave washer / flat washer / o-ring / worm gear nut)

RP-2049 Gear housing / 2 pins / bearing / o-ring seal / 2 retaining rings / nut

RP-3523 Base plate / 10 screws / rubber boot

RW-2000 Outside roof wedge (used on slanted roofs)

IW-5000 Interior roof wedge (used on slanted ceilings)

RP-0154 Boot (only needed for Sensar I and II)

RP-6200 Ivory RP-6300 White Directional handle / ceiling plate / 4 screws / spring (RP-6822 included) / decal


EK-1036 Directional handle extension


RP-6822 Spring

RP-2658 Nylon bearing

RP-5895 Ivory RP-6795 White Crank / set screw / hex shaft

RP-5000 Crank / set screw / round shaft







(fits RP-6200/RP-6300)