


Easy DVD Setup Guide


Connecting To Antenna

Connect the supplied AM/FM antennas to listen to the radio.



- In order to improve the signal, move AM loop antenna away from system and other equipment.
- Extend FM antenna fully.
- Keep the FM antenna as horizontal as possible after connection.

When connecting the supplied AM loop antenna, connect two black cords to AM and ground




- If the FM reception is poor, use a 75 Ω coaxial cable to connect system to an outdoor FM antenna as above.
- If you connect the system with outdoor FM antenna, you should earth the system in order to avoid lightning strike.
- Do not connect the earth wire to gas pipe to prevent gas explosion.

Easy DVD Setup Guide

Connecting To External AV Signal Source


Connections should be made as follows:

Connect the L/R audio cables according to the marks on the rear panel of the unit: Left audio cable is plugged into the upper jack; the right audio cable is plugged into the lower jack.




AV SIGNAL SOURCE

Connecting To TV Signal Input Source



Connecting To the Power Adapter

This unit is powered via the switching power adapter (supplied). See the below figure for details:



1. Connect the AC adapter to jack marked with "DC 12V IN" on the rear panel of the unit.
2. Plug the two-prong end of the power cord to the grounded electrical socket.
3. When not using the unit, turn off the power of the unit first, and then unplug the power Supply to prevent malfunctions.