


BI-FOLD RANGE COVER INSTALLATION INSTRUCTIONS

No tools required to install your Bi-Fold Range Cover.

To install Bi-Fold Cover, hook the rear pivot hinges over the shoulder pins located on each side at rear. See sketch below:



After hooking the pivot hinges on the shoulder pins, lower Bi-Fold Cover down onto main top.

COUVERCLE A DEUX REPLIS POUR TABLE DE CUISSON INSTRUCTIONS D'INSTALLATION

Aucun outil nécessaire pour installer votre couvercle à deux replis pour table de cuisson.

Pour installer le couvercle à deux replis, accrochez les charnières pivotantes sur les goupilles situés aux coins arrières de chaque côté de la table de cuisson. Voir le schéma ci-dessous:

Après avoir accroché les charnières pivotantes sur les goupilles, baissez le couvercle sur la table de cuisson.



REPLACEMENT PARTS LIST FOR:

SR3S (SHORT OVEN)
SR3L (LONG OVEN)
SC3 (SLIDE-IN COOK TOP)



Only factory authorized parts are to be used. Do not attempt to repair defective parts.

When ordering repair parts from a Suburban Service Center or your local dealer, always give the following information:

1. Part Number (Not Item No.)
2. Part Description
3. Model No., Serial No.
4. Number of Parts Required

*Denotes piezo ignition ("E" models only)

**All screws and nuts are steel - Do not substitute with aluminum, brass, plastics or other materials.




Figure 1




Figure 2

Item No.	Description	SR3S	Part Numbers SR3L	SC3
1	Trim Top RT	031040BK	031040BK	—
2	Top Almond	101757AL	101757AL	101757AL
	Top Black	101758BK	101758BK	101758BK
	Top White	101749WH	101749WH	101749WH
**3	Screw 10 x 3/8 Phillips Truss Hd, Zinc Plated Silver Finish	Buy Local	Buy Local	Buy Local
**4	Nut 8-32 Hex Lock Thin Zinc Plated	Buy Local	Buy Local	Buy Local
5	Strike	Buy Local	Buy Local	Buy Local
6	Manifold Complete (Order Individual Parts)	063308	063308	063308
7	Wire Piezo			
8	Burner Left Rear with Piezo	*232494	*232494	*232494
	Burner Left Rear	*010836	*010836	*010836
9	Burner Right Rear with Piezo	010840	010840	010840
	Burner Right Rear	*010838	*010838	*010838
10	Burner Center with Piezo	010842	010842	010842
	Burner Center	*010837	*010837	*010837
11	Bushing Burner	010841	010841	010841
12	Catch	121886	121886	121886
13	Panel Control with Piezo & Oven	063309	063309	063309
	Panel Control with Oven	*101768	*101768	—
14	Knob Oven	101769	101769	101769
15	Knob Burner Rear	140215	140215	—
16	Knob Burner Front	140217	140217	140217
17	Knob Piezo	140220	140220	140220
18	Screw Piezo Mounting	*140216	*140216	*140216
19	Piezo	*121894	*121894	*121894
**20	Nut 10-24 Keps Cad Plated	*161149	*161149	*161149
**21	Screw #10-24 x 3/8 Phillips Pan HD Zinc Plated	Buy Local	Buy Local	Buy Local
22	Trim Top LT	Buy Local	Buy Local	Buy Local
23	Box Burner	031039BK	031039BK	—
24	Clip Grate	090504	090504	—
25	Bolt Shoulder	121910	121910	121910
		121892	121892	121892

4

Item No.	Description	Part Numbers		
		SR3S	SR3L	SC3
**26	Screw 10 x 3/8 Phillips Truss HD Black Oxide	Buy Local	Buy Local	—
27	Pad Rubber	140214	140214	140214
28	Trim Vent	031044BK	031044BK	031044BK
29	Grate	031047	031047	031047
30	Trim Top Rear	—	—	031057BK
31	Trim Top Right	—	—	031061BK
32	Box Burner	—	—	090505
33	Manifold Complete (Order Individual Parts)	—	—	—
34	Panel Control with Piezo	—	—	*101708
	Panel Control	—	—	101709
35	Rod Safety	—	—	140223
36	Trim Top Left	—	—	031060BK
37	Fitting Brass	171513	171513	171513
38	Regulator	161140	161140	161140
39	Tube Valve	171528	171527	—
40	Manifold	171523	171523	—
41	Valve Burner	161148	161148	161148
42	Valve Burner	161145	161145	161145
43	Tube Pilot	171526	171525	—
44	T-Stat Oven	161150	161150	—
45	Screw Oven T-Stat Mounting	171524	171524	—
46	Bolt Valve Mounting	171511	171511	—
47	Manifold	—	—	171531




Figure 3




Figure 4

Item No.	Description	Part Number		Item No.	Description	Part Number	
		SR3S	SR3L			SR3S	SR3L
48	Cabinet Wrap	101723	101723	71	Side Oven Left	110720	110720
49	Insulation Back	071054	—	72	Clip Bulb	063311	063311
50	Insulation Wrap	071052	—	73	Top Oven	101720	101720
51	Rack	031059	031059	**74	Nut 6-32 Keps Zinc Plated	Buy Local	—
52	Screw Shoulder 6-32	121903	—	75	Gasket Vent	071049	071049
53	Panel Bottom	101725	—	76	Vent	260248TB	260248TB
54	Burner Pilot	161153	161153	77	Trim Front Left	031043BK	—
55	Cover Plate	063323	063323	78	Trim Front Right	031042BK	—
**56	Screw 10-24 x 1.5 Hex Washer	—	—	79	Bracket Panel	063339	—
	HD Zinc Plated	Buy Local	Buy Local	80	Back Oven	101719	—
57	Valve	161152	161152	**81	Screw 10-24 x 5/16 Phillips Pan	—	—
58	Bracket Valve	063307	063307		HD Cad Plated	Buy Local	Buy Local
59	Side Oven Right	110719	—	82	Trim Front Right	—	031049BK
60	Burner Oven	010839	010839	83	Insulation Back	—	071055
61	Frame Front	101721	—	84	Insulation Wrap	—	071053
62	Door Oven Almond	031055AL	—	85	Bracket Burner	—	063314
	Door Oven Black	031055BK	—	86	Front Frame	—	110732
	Door Oven White	031055WH	—	87	Door Oven Almond	—	031063AL
63	Door Oven Glass	031056	—		Door Oven Black	—	031063BK
64	Hinge Return	150127	150127		Door Oven White	—	031063WH
65	Spring Door	150125	150125	88	Door Oven Glass	—	031062
66	Bottom Oven	101730	101730	89	Extension Frame Front	—	110733
67	Support Bottom	063302	—	90	Panel Bottom	—	101779
68	Bracket Hinge	063301	063301	91	Baffle Heat	—	040455
**69	Screw 10 x 3/8 Phillips Truss HD	Buy Local	Buy Local	92	Wrap Oven	—	110731
70	Cabinet Bottom	101731	101731	93	Cabinet Wrap Broiler	—	101702
				94	Trim Front Left	—	031050BK