



Keystone

How to set the Orientation and Null

First you want to set the Orientation. Below is a step by step tutorial.

1. Turn off the touch pad, making sure no lights are on.
2. Push and hold the All Retract button.
3. While holding the All Retract button down continuously, push and release the Power button.
4. After the touch pad turns on release the All Retract button.
5. Push and release the Left Up Arrow on the manual buttons.

Now the Orientation is set.

Next you will need to set the Null. Below is a step by step tutorial.

1. Level the trailer by using the manual Front Up and Down Arrows. Get the coach level from front to back.
2. Turn off the touch pad, making sure no lights are on.
3. Push and hold the Auto Level button.
4. While holding the Auto Level button down continuously, push and release the Power button.
5. After the touch pad turns on, let it beep 5 or 6 times then release the Auto Level button. The touch pad will give you an acknowledgement beep (slightly different tone).

You are finished setting Orientation and Null at this time.

Next you will want to test the system.

1. Press the All Retract button and wait for the rear jacks to come up if extended.
2. Once the rear jacks are retracted and the lights on the touch pad for the rear jacks are off, extend the front jack(s) until the trailer is nose high just like you would if you were removing the trailer from the truck.
3. Press Auto Level and wait for the system to finish leveling.
4. Check the level if it is within $\frac{1}{2}$ of a degree then the system has done its program. *A $\frac{1}{2}$ degree defined (place a 4' level on the floor and raise up one end $\frac{7}{16}$ ") this is $\frac{1}{2}$ of a degree.*

If the unit is not level use the manual Front Up and Down Arrow buttons to get the unit level and then follow above steps to reset the Null and try again.