



Quality in the Making

Air Bed Start-Up Guide

We hope you enjoy your new Sleep & Store Sofa and the many versatile options it provides. Your sofa converts into the air bed in minutes and comes with a large storage drawer, all without sacrificing seating comfort. In your Sleep & Store Sofa, your air mattress comes stored in a convenient Storage/Travel Bag with both a built-in pump and an additional battery powered pump (four D batteries not included). The Storage/Travel Bag is equipped with two handles that, along with the battery-operated pump, makes your mattress totally mobile. **It is recommended you store your air mattress in the convenient Storage/Travel Bag to provide the maximum protection between uses (see instructions below).** However, you can leave your air mattress strapped to the metal frame so your sleep option is always ready (see instructions to the right). Some upholstery fabrics do not permit the mattress to slip down. So you may need to push the mattress out from under the back and off the cushion once the back is folded up into the sofa position. The Storage/Travel Bag may be left on the frame even if the mattress is attached. (It is recommended that your mattress be warmed to a temperature above freezing before handling the air mattress.) Please follow instructions on reverse side for proper setup of the sofa pull out bed and attachment of your air mattress to the metal frame.

Folding Instructions if air bed is left attached to frame




Fold over 6" from both sides once before folding the sofa back up

Folding Instructions if put in Storage/Travel Bag



Fold over 12" of mattress from left to right.




Next begin folding the mattress over 12" at the foot end and continue until the entire mattress is folded while taking care that the plug prongs are packed in such a way as to not damage the mattress.



Once you are done folding, you may need to flip the mattress over once so that the internal pump is at the right end corner of the frame nearest to you, and the internal pump is positioned just left of the battery powered pump.



Sleep & Store Sofa



Internal air pump




Battery-powered air pump (four D batteries not included)




Back of sofa pulled out in first position




Bed in second position with the legs extended fully out on the ground



Displaying the tension strap that need to be attached together before inflation



The six straps only need to be connected to the metal frame if you choose not to store the mattress in the recommended Storage/Travel bag. If attaching, the two center straps need to be on opposite sides of the center frame wire to keep the mattress centered, and then attach the rest of the straps.



Displaying the mattress full out with the internal pump on the back right side of the frame. This is how the mattress should appear right before inflation.



The air mattress fully inflated