THE FLUSHER


(Part#: 571 2P & 571 2PS)

THE FLUSHER protects your black water tank from buildup and blockages. This easy-to-use system eliminates the need for hooking up hoses inside the RV to flush out the black water holding tank. Plus, it helps control unpleasant odors. THE FLUSHER meets all applicable codes for wasteholding tank flushing systems.

USER INSTRUCTIONS

- 1. Connect Sewer Hose.
- 2. Open Black Tank Valve, let tank drain.
- Attach garden hose to water inlet marked "Sewer Valve Must Be Open When Using This Inlet", Open faucet valve and flush until water is clear from discharge hose.
- 4. Disconnect garden hose from faucet and lay on ground to drain before disconnecting from water inlet.





Caution!

Dump valve must be open anytime a hose is connected to this system.

DO NOT alter this system by adding check valves or other components **DO NOT** use the same hose to fill your potable (fresh) water as hose used for **THE FLUSHER**

Manufactured by:

B&B Molders LLC

www.bandbmolders.com Phone: (574) 259-7838 Fax: (574) 259-7939

