



DESIGNED TO MOVE [YOU][®]

AWM965 Quick Reference Guide

Basic Operation



VOL: Rotate *clockwise* to INCREASE or *counter-clockwise* to DECREASE volume output.

AUDIO: Each press of the control will bring up the following AUDIO ADJUSTMENT options: BASS, TREBLE, BALANCE (left to right), & FADE (front to back).

ADJUST LCD BRIGHTNESS: Press and hold to access the user menu. Press to navigate to "LIGHT". Rotate to adjust the standby mode LCD brightness from "LIGHT 1" (least bright) to "LIGHT 3" (brightest).



MUTE: Press to MUTE audio.

POWER: Push to turn ON or OFF.

T/F CLOCK: Press to display CLOCK.

SPEAKER OUTPUT: Press any speaker button (SPEAKER A, SPEAKER B, or SPEAKER C) to control corresponding speaker output from the stereo. Red light above each button will illuminate when selected speaker is turned on.

AUX A/V IN: Insert 3.5mm audio/video jack.

AM/FM Tuner Controls



VOL: Rotate *clockwise* to INCREASE or *counter-clockwise* to DECREASE volume output.

AS/PS: Press to SCAN through currently stored presets. Press & hold to STORE strongest broadcast stations in your area.



AM/FM: Press to directly access TUNER MODE. Press to select between two AM BANDS (AM1 & AM2) & three FM BANDS (FM1, FM2, & FM3).

MUTE: Press to MUTE audio.

STATION STORE BUTTONS:

Press & hold to store current channel playing. Momentarily press to recall stored channel. NOTE: you can store up to 30 channels (6 channels per band FM1, FM2, FM3, AM1, AM2).

TUNE/TRACK: Rotate *counter-clockwise* to TUNE DOWN in frequency in AM or FM Mode. Rotate *clockwise* to TUNE UP in frequency AM or FM Mode. Rotate and hold to scan to next strongest station.




VOL: Rotate clockwise to INCREASE or counter-clockwise to DECREASE volume output.

MUTE: Press to MUTE audio.

MENU: Press to access main DVD MENU.

DVD/USB: Press to select DVD/USB mode.



TUNE/TRACK: Rotate clockwise to tune to NEXT TRACK or CHAPTER/TITLE. Rotate counter-clockwise to tune to PREVIOUS TRACK or CHAPTER/TITLE. In CD MODE, rotate and hold to FAST FORWARD or REWIND current play. In DVD MODE, rotate and hold to enter FAST FORWARD/RW. Momentarily turn to step through x2, x4, x8, x20. Press PLAY to resume.

EJECT: Press to EJECT CD or DVD.

PLAY/PAUSE: Press to PLAY or PAUSE current audio or video.

INTRO SCAN: Press to play each track for 10 seconds in sequential order. Press again to SELECT desired play.


RPT: Press to REPEAT current playing track. Press to release function.

RDM: Press to play each track in RANDOM order. Press again for NORMAL play.

STOP: Press to SUSPEND disc play. Press PLAY/PAUSE to RESUME disc play.

LANG: Press to select AUDIO LANGUAGE when in DVD MODE.

USB: Plug in USB device



MENU: Press to access main DVD MENU.

DIRECTIONAL ARROWS: Press to move cursor to desired MENU ITEM. Press ENTER to select desired MENU ITEM.

T/F: Press to display CLOCK.

STOP: Press once SUSPEND disc play. Press PLAY/PAUSE to RESUME disc play. Press twice to completely stop disc play.

LANG: Press to select AUDIO LANGUAGE.

SUBTITLES: Press to select CLOSED CAPTIONING. Continue to press to select AUDIO LANGUAGE.

SETUP: Press to enter SETUP MENU.

MUTE: Press to MUTE audio.

EJECT: Press to EJECT DVD.

CHAPTER SKIP: Press to skip to NEXT or PREVIOUS chapter.

ENTER: Press to select menu option.

FAST FORWARD/REWIND: Press to FAST FORWARD or REWIND current play. Continue to press to enhance the speed. Press PLAY/PAUSE to resume current play.

PLAY/PAUSE: Press to PLAY or PAUSE current audio.

TITLE: Press to enter TITLE MENU. Use the DIRECTIONAL ARROWS to choose menu item. Press ENTER to select.

RPT: Press to REPEAT current CHAPTER. Press again to release function.

SOURCE: Press to select for PLAYBACK.

ZOOM: Press to ZOOM in on current picture. Press repeatedly to change MAGNIFICATION LEVEL of current picture.

ANGLE: Press to select different visual angle if stored on DVD.

GOTO: Press to view CHAPTER, TRACK, & TIME. Press again to clear.

DISPLAY: Press to DISPLAY current playback information on the screen.



TUNE/TRACK: Rotate UP or DOWN to adjust HOUR and MINUTES once in CLOCK MODE or ALARM SETTING MODE.

T/F CLOCK: Press to display current time. Press & hold to enter CLOCK SETTING MODE. Rotate TUN/TRK encoder knob to adjust the HOUR. Press T/F again and rotate TUN/TRK encoder knob to adjust the MINUTES. Once desired time has been selected, the time will set after 5 seconds.

ALARM: Press ALARM SET to cycle through SLEEP TIMER MODE. Press and hold to enter ALARM SETTING MODE. Rotate TUN/TRK encoder knob to adjust the HOUR. Press ALARM SET again and rotate TUN/TRK encoder knob to adjust the MINUTES. Once desired time has been selected, press ALARM ON/OFF to turn ALARM MODE ON or OFF.