



CARE AND REPAIR INSTRUCTIONS FOR SUPERFLEX ROOF MEMBRANE SEALANTS

During routine cleaning (3-4 times a year), all Superflex roof sealants should be inspected for any voids or cracking. If the roof sealant shows signs of cracking, remove any loose sealant. If the loose sealant cannot be pulled off by hand, it still has adhesion to the Superflex roof membrane and should be left alone. **Do not use sharp tools (putty knife) that could puncture the Superflex roof membrane.**

Clean all areas to be resealed with a non-abrasive household cleaner, such as Top Job or Spic-N-Span, using a medium-bristled scrub brush. This area must be dry before continuing. **Solvents should not be used during cleaning. Solvents can damage existing sealants and may weaken plastic roof components.**

Apply a generous amount of ***Alpha Systems 1010 Non-Sag Sealant*** over top of any existing sealant needing resealed. Please note **ONLY ALPHA SUPPLIED SEALANTS SHOULD COME IN CONTACT WITH THE SUPERFLEX ROOF MEMBRANE.**

To order your Alpha sealant today, call Yvonne Christian toll-free at 800-462-4698. Please allow 3-5 business days before your product ships from our facility. Shipping charges will be added to your order.